

# RT SPRING PRELOAD COLLARS

<IP SMPC PL COLLARS.doc> © P Thede 5-21-15

Thank you for choosing Race Tech Products. Here are a few tips that will help install the collars.

1. On many models you must completely disassemble the shock. If needed, remove the shaft and the spring guide, otherwise...
2. Remove the stock collars.
3. Clean and grease the threads. Yes, grease the threads. Grease the contact surfaces as well.
4. Install the Locking Collar (the smaller one) with the ridge facing up, towards the Adjusting Collar.
5. Install the Adjusting Collar with the flange facing up, away from the Locking Collar.
6. Reassemble the shock.

